

Prepare the Equipment

 Shut off all valve lines leading to and from equipment, including pressurized flush if any. Bleed off equipment pressure.

Do not use system pressure to blow out (remove) packing rings.

- 2. Remove all old packing rings and the lantern ring by using the proper size packing removal hook.
- 3. Check the shaft/sleeve for nicks and score marks, repair or replace as necessary. Clean stuffing box bore if required.




4. Place adhesive back PTFE gasket tape on raised face of each busing half.



 Place bushing halves over shaft/sleeve and push firmly together.




 Split O-ring(s), place into O-ring groove(s) on bushing outside diameter (OD). and bond ends.



 Insert bushing into stuffing box leaving approximately 1/2" exposed.



- 8. Align a lantern ring hole with flush port by slowly rotating bushing.
- Firmly seat bushing against bottom of stuffing box utilizing a split installation bushing and gland follower.



Split Installation Bushing



CPR BUSHING

Installation, Operation & Maintenance Instructions


PAGE

10. Install 1st packing ring with ring joint at approximately 1 o'clock postion. Seat ring firmly using split installation bushing and gland follower.



"S" twist ring and insert around shaft.


11. Repeat step ten seating each additional ring individually, staggering ring joints 90° to 180° apart.



- 12. Seat final ring firmly with wrench. Loosen gland nuts and finger tighten.
- 13. At minimum, gland follower lead-in should be approximately 1/8" to 3/16". The remaining exposed portion of gland follower should at least equal the cross section of packing used, allowing for future gland adjustments.
- 14. Rotate shaft by hand to ensure shaft is not binding.







For optimum performance flush pressure should be maintained at higher pressure than process.



North America	Europe	Latin America	Middle East & Africa	Asia Pacific
United States of America	United Kingdom	Brazil	United Arab Emirates	Singapore
Tel: 1-847-967-2400	Tel: 44-1753-224000	Tel: 55-11-3371-2500	Tel: 971-481-27800	Tel: 65-6518-1800
Fax: 1-847-967-3915	Fax: 44-1753-224224	Fax: 55-11-3371-2599	Fax: 971-488-62830	Fax: 65-6518-1803

If the products featured will be used in a potentially dangerous and/or hazardous process, your John Crane representative should be consulted prior to their selection and use. In the interest of continuous development, John Crane Companies reserve the right to alter designs and specifications without prior notice. It is dangerous to smoke while handling products made from PTFE. Old and new PTFE products must not be incinerated. ISO 9001 and ISO14001 Certified, details available on request.